


Note:

1. All dimensions are in mm

2. Tolerances not informed on the drawing according to the mounting tolerance table.


Mounting tolerance	Dimensions range	Tolerance
	0<D≤400	±10
	400<D≤1000	±20
	1000<D≤2000	±30
	2000<D≤4000	±35
	4000<D≤8000	±40

Unit: mm



<b>Hoyer Motors</b>		<b>DEBUR AND BREAK SHARP EDGES</b>	
Over Hadsstenvej 42, DK-8370 Hadssten			
Tel : +45 86982111			
Fax: +45 86981779			
www.hoyermotors.com			
REV.	LOCATION	DESCRIPTION	DATE
0	N/A	First issued	07/08/2024
RESP.	L&T	APPROVED	Hoyer

<b>DRAWING NOT IN SCALE</b>		<b>DWG NO.:</b>	
<b>OUTLINE DRAWING</b>		<b>TD-ID-D2615</b>	
<b>TITLE:</b>		<b>A3</b>	
<b>HMA2-80 1-4P-B35</b>		<b>SHEET 1 OF 1</b>	



Representation of the machine is illustrative only  
Some features may not be represented  
For installation or maintenance, consult operation manual

<b>Protection:</b>	IEC 60034-5	<b>Machined Part:</b>	ISO 2768
<b>Dimension:</b>	IEC 60072	<b>Weld Constr.:</b>	ISO 8015
<b>Tolerance:</b>	ISO 286	<b>Castings:</b>	ISO 8062
<b>Key:</b>	IEC 60072		

<b>SCALE:</b>	1:5	<b>Weight:</b>	10 kg
---------------	-----	----------------	-------